

Proxmox

- [Fix unmounted disk](#)

Fix unmounted disk

Hit F9 on start up to enter the Raid Controller.

Either replace Disk or press F2 when asked if you still want to use this disk after the error.